

# **BJ3679** MOVEMENT INSTRUCTION






## A. Features

- ▶ 12 Digits LCD Display, Display Hour, Minute, Second, Month, Day, Year(2000年~2069年) and Week.
- Dual Time
- > 5 group alarm.
- ➤ Chime on every hour .
- > 3 group count-down function.
- Summer time .
- Chronograph function .
- Slip operate stopwatch .
- > 12 / 24H format selectable, Auto Calendar
- ➤ 1/100 second Chronograph
- > key tone
- ➤ EL backlight

## **B**. Operational Manual



## 1. At any state , press A key EL backlight for 3s.

### 2. Time Setting

At normal mode ,press D key over 3 seconds ,"second "flash ,then press C key to zero resume .Press D key to select mode in turn as following: "Minute ","Hour ","Year ","Month ","Day ",press B or C key to set while each item flash (B for backwards, C for forwards) .And then press D key over 3 seconds to return normal mode and setting complete.

## > Summer time setting

At time setting mode ,press D key over 3 seconds entering summer time setting mode when "minute" flash .Press D key On/Off summer time ,then press D key to return .

NOTE: Normal time will auto faster a hour at Am.2.00 on the last Sunday in Mar. of Gregorian calendar and lower a hour at Am2.00 on the last Sunday in Oct. of Gregorian calendar when ON summer time. If off the function of above mentioned will be canceled.

#### > Double time setting

At normal mode ,press C key entering the second time state ,("T2" showing at the downcorner of the LCD) , press D key over 3 seconds and "hour" flash ,then press B or C key setting , (B key for backwards ,C key for forwards .) Press D key over 3 seconds to return .

2015-09-16 Model: BJ3679 Page: 1/3 Edition: A



# **BJ3679** MOVEMENT INSTRUCTION



### 3. Daily Alarm Chime setting

- ➤ Alarm and Chime On/Off.
- At alarm mode ,press D key over 3 seconds , "AL" will flash , this time press C key on / off Alarm (ALM will display when alarm on) or Chime ("CHIME " will display when chime on ).

## > Alarm setting

At alarm mode ,press D key over 3 seconds ,"AL"will flash ,then press D key again to alternative "hour "or "minute" setted ,press B or C key setting (B for backwards ,C for forwards ).Press D key over 3 seconds to complete .

#### > Alarm select

5 group alarm can be setted at the same time .the method is entering alarm mode ,press C key to select from AL 1 to AL 5 .The alarm setting is same as above ,and ringing 23 seconds for every group .

#### 4. Count-down time function

At count-down time mode ,press D key over 3 seconds and "hour ","minute "flash ,press B or C key setting (B key for backwards ,C key for forwards ).Press D key over 3 seconds to complete ,and press D key again to star or pause count-down time .

#### **Count-Down Select**

- > 3 group count-down time can be setted at the same time, the method is entering count-down mode, press C key. to select from T 1 to T 3 (the max count-down time: T1=90 Minutes, T2=24 hours, T3=1825 days). The method of setting is same as above. When count-down finish, the hint sounds will click 3 seconds then return to setting state. Press D key again to turn on count-down circle.
- NOTE: The account method of T2: The actual count-down time is the result of setting time subtract current time. The account method of T3: The actual count-down days is the result of setting date subtract current date.

## 5. Chronograph function

- > At chronograph mode ,press C key to alternate circle chronograph (SPL) or slip chronograph (LAP) mode .
- ➤ Press D key to start chronograph ,press again to pause ,and again to continue .Press C key to zero resume when stop ;And press C key to record current time when in process .
- NOTE:At "SPL"'s slip chronograph, press D key to start, and record the first person's time; At one time press C key to record the second person's time, and display on the half of the LCD. Press C key again showing the third person's time on the half of the LCD, and by analogy.

#### > Selectable 12/24 format

In process of step one adjusting "hour ",press B or C key till "H" on LCD ,it means 24format ;If "A" or "P" on LCD ,it means 12 format ,AM means morning ,PM means afternoon .

2015-09-16 Model: BJ3679 Page: 2 / 3 Edition : A



# **BJ3679** MOVEMENT INSTRUCTION



## C. Specifications

➤ Module dimension : Ф40.0mm

► Module thickness (inclusive buzzer) : 9.90mm

➤ Working temperature range :  $-10^{\circ}\text{C}\sim60^{\circ}\text{C}$ 

➤ Working voltage : 3.0V

➤ Time accuracy : ±60sec/month

➤ Battery code and capacity : CR2032(capacity: 220m Ah)

➤ Static average current : ≤3.39u A (Static maximum current : 12.0uA)

➤ Alarm average current : ≤2.00m A (Alarm maximum current : 6.0mA)

► Average current of EL backlight : ≤9.77m A (Maximum current of EL backlight : 12.0mA)

➤ Battery life (85%) : ≥24 months (Japan Lithium)

According these standards to calculate battery life: EL backlight illuminates 4 times (12 seconds) per day. Alarm tone sounds once (60 seconds) per day.

	Prepared	Checked	Approved
Name	冯碧颜	赵星亮	汤志平
Date	15/09/16	15/09/16	15/09/16

2015-09-16 Model: BJ3679 Page: 3 / 3 Edition: A